

M1142 TFFT, M1158 HEWATT Trucks...

AVOID FROZEN PIPES!

HELLO, SOLDIERS!
I WAS ON MY
FACEBOOK PAGE THE
OTHER DAY AND ONE
OF MY FRIENDS ASKED
US TO TALK ABOUT
FIREFIGHTING.



PS 719

14

OCT 12

HE WANTED US
TO REMIND YOU
FIREFIGHTING
ENGINEERS THAT
IT'S TIME TO
BLOW OUT YOUR
TACTICAL FIRE
FIGHTING TRUCKS
(TFFTS) AND
HEMTT-BASED
WATER TENDER
TRUCKS (HEWATTS)
BEFORE THE COLD
WEATHER HITS.

TOO
EASY!

IF YOU DON'T BLOW
WATER OUT OF THE
PUMP AND PIPES IN
YOUR TFFT AND HEWATT
TRUCKS, COLD WEATHER
BELOW 32°F COULD
DAMAGE THEM WHEN
THEY AREN'T IN USE.

YOU CAN FIND THE BLOWOUT PROCEDURE
S FOR THE TFFT IN WP 0044 OF
TM 5-4210-249-13&P-1 (FEB 09).

BLOWOUT PROCEDURES FOR
THE HEWATT ARE IN WP 0033 OF
TM 9-2320-328-13&P-1 (MAR 09).

