Under the Hood

Air Filter Canister Removal

Use a little TLC when you remove the air filter element's canister housing on the curbside of the vehicle. Do **not** set the housing on the sensor wire for the vehicle's fire suppression system (FSS). The weight of the housing will nick or cut the wire, causing the FSS to activate without warning.



If that happens, you'll be blasted by a loud explosion, not to mention the gray, fine chemical dust that'll cover you and the engine and everything else within an arm's throw. What a mess! So easy does it when you remove the canister housing.



Sensor Wire Attire

Make it a habit to eyeball the FSS's sensor wire where it's attached to the engine shield. Look for a loose wire and connections. A loose wire that touches the engine also sets off the FSS!

And be careful where you place your boot while stepping around the engine. It goes without saying—do **not** step on the sensor wire!